



## LIEBHERR PREMIUM INTEGRATED BIO-FRESH FRIDGE - SIBP1650

- Integrable built-in refrigerator with BioFresh
- Niche dimensions : H-87,4 - 89 x w-56 - 57 x d- 55,0 cm
- Total capacity : 84 l
- Installation type : integrated
- Door mounting : Fixed door
- Energy efficiency class : C
- Energy rating : A+++
- Freshness technology : BioFresh
- “Magic Eye” controls
- Door on door

5 year warranty



BioFresh

At a temperature just above 0 °C and the ideal humidity, fruits and vegetables, meat, fish and dairy products retain their healthy vitamins, delicate aroma and appetizing appearance much longer than in the conventional cooling part.



Door alarm

For the safe protection of the food, the acoustic door alarm warns after 60 seconds of open door.



Parental

The parental control is programmable in such a way that an accidental switching off of the device is prevented. If parental control is turned on, this is indicated by an icon in the MagicEye.



HolidayMode

For BioFresh devices, the HolidayMode regulates the cold room temperature to approx. +15°C. This can be used to save energy in the event of a prolonged absence with an empty refrigerator without creating an unpleasant odor in the interior. For devices with a freezing room, the freezing room temperature is left as set.



Changeable door stop

The devices are factory equipped with a right door stop. With the possibility to change the door stop, the device can always be operated optimally in the installation area.



## Integrable built-in devices

The appliances can be easily installed behind the furniture door of the conversion and thus perfectly integrated into the kitchen. This creates an optically uniform kitchen front. To note is the technique of furniture door assembly. Fixed door mounting: Furniture and appliance door are firmly connected to each other by attaching the furniture door directly to the appliance door. Drag door mounting: The furniture door is attached directly to the high cabinet and is connected to the device door via sliding rails. When opening and closing, the furniture door slides along the rails.



Furniture and appliance door are firmly connected by attaching the furniture door directly to the appliance door.